artifax

RECHARGEABLE

HANDHELD FAN

ART-B-1



Contact Information

+91-8459059329

care@artifax.in

www.artifax.in

Product Overview

This handheld fan is a compact, portable cooling device perfect for on-the-go use. With it's light weight design and powerful battery, it provides a convenient solution for staying cool.

Features

- **Lightweight & Portable:** Compact design for easy portability and storage.
- **Long Battery Life:** 800mAh lithium battery for extended use on a single charge.
- **Multiple Speed Options:** Adjustable speed settings for customized airflow.
- **Quiet Operation:** Low noise design for undisturbed cooling.
- **USB Rechargeable:** Convenient charging with any standard USB power source.
- **Durable Build:** Made with high-quality materials for long-lasting use.
- **Easy to Clean:** Simple cleaning with a soft cloth.
- **Ergonomic Grip:** Comfortable handle design for easy and secure use.
- **Versatile Usage:** Ideal for outdoor activities, travel, or indoor use.
- **Energy Efficient:** Low power consumption for extended battery life.

Technical Parameters

- **Product Size:** 21x10x4cm
- **Packaging Size:** 22x4x11cm
- **Single Weight:** 143.2g
- **Battery Capacity:** 800mAh
- **Power Source:** Rechargeable Battery
- **Charging :** USB Port

Troubleshooting

- **Fan Not Turning On:** Ensure the fan is fully charged and try again.
- **Weak Airflow:** Clean the fan blades and check if the speed is adjusted.
- **Charging Issues:** Try a different USB cable or power source.
- **Battery Not Holding Charge:** Charge the fan longer or replace the battery if needed.
- **Unusual Noise:** Clean or realign the fan blades.
- **Charging Indicator Not Lighting:** Ensure the cable is securely connected or try another charger.
- **Fan Overheating:** Allow the fan to cool down before using it again.

How to Use

Charging the Fan:

- Connect the fan to a USB power source using the provided cable.
- Charge fully before first use (Approx. 2-3 hrs.)

Turning On the Fan:

- Press the power button to turn on.
- The fan operates at the default speed.

Adjusting the Speed:

- Press the power button again to change speed settings

Turning Off the Fan:

- Press the power button to turn off.

Charging the Battery:

- When not in use, connect the fan to a USB charger.
- The battery indicator (if available) will show when the fan is fully charged.

Caution and Safety Guidelines

Charging: Use only the provided USB cable and certified power source.

Battery Care: Disconnect once fully charged.

Water Exposure: Keep away from water to avoid damage.

Storage: Store in a cool, dry place.

Supervision: Not suitable for children under 3 yrs.