



4MP Wi-Fi Dome & Bullet Camera

User Manual



Please read the Quick Guide carefully before using the camera


About This Product

This manual is only a guide for related products and may differ from the actual product, please refer to the actual product. Due to product version upgrade or other needs, this manual may be updated without further notice!


Product Introduction

This manual is suitable for various types of cameras. (The appearance may be different due to different batches. The details are subject to thereceipt. This manual is only for the installation instruction of this series of equipment)

1.1) 3MP Wi-Fi Dome Camera



1.2) 3MP Wi-Fi Bullet Camera




Indicator Light Status:

1. Blinking: Device is connecting to the network.
2. Stable Device is successfully connected to the network

2) Installing the SD Card

Note: Carefully check the SD card slots before insertion. Make sure to insert the cards in the correct positions and orientations.

1. Power **OFF** the device before inserting any cards.
2. Insert a compatible **SD card** into the **SD card** slot, if required for storage or recording.
3. **Power ON** the device after SD card are properly inserted.



3) App Installation

• Download and Installation

Use your mobile phone to scan the below QR code to download and install “**Artifax SmartHub**” APP and follow the APP prompts to complete user registration



Artifax SmartHub
Android App



Artifax SmartHub
iOS App


Note : For iOS system, it requires iOS 9.0 version or above. for Android, Android 5.1 or above

3.1) Account Registration and Login:

Registration: If you are a new user, click the “**Register**” button on the login interface. Enter your phone number, email, or other required details, set a password, and follow the on-screen instructions to complete the registration process. You may need to verify your identity using an OTP (One-Time Password) sent to your phone or email.


3.2) Login:

On the login interface, enter your account, phone number, or email along with the corresponding password, then click the “**Login**” button to log in.




4) Adding a Device in the App

Open the app and click the
“+ Add Device” icon



Adding the camera to the App

Select **Wi-Fi Camera** from the type of camera and tap on the appropriate icon to select the model of the camera.




4.1) Device Power-On Confirmation

Click the **More Method** option located in the upper-right corner of the screen.

More Method

After selecting “**More Methods**”, tap on “**Wi-Fi Configuration**” to proceed.



4.2) Device Power-On Confirmation



On the Add Device screen, you will see on-screen instructions. If your camera is already powered on, select the checkbox that confirms the device is **Powered On**, then click “**Next**” to proceed with the setup.

Note: You heard the device network setup prompt. Click on the check box to proceed to the next step.





4.3) Connect to Your Wi-Fi

- The screen will prompt you to connect to Wi-Fi manually.
- Tap **“Connect Your Wi-Fi”**.
- Select your Wi-Fi network (SSID).
- Enter your Wi-Fi password, then tap **“Next”** to continue.
- After tapping **“Next”**, confirm your Wi-Fi and password, then tap **“Confirm, Next”** to proceed.



4.4) Connect to Device Wi-Fi

- Tap **“Go to Settings”** in the app.
- On your mobile device, open the Wi-Fi Settings.
- Look for the device’s Wi-Fi name (**e.g., WEIPLXXXXXXXX**) and select it.
- Enter the default password: **WEIPL1234** to connect.
- Once connected, **go back** to the app to continue the setup





4.5) The configuration process should take less than two minutes to complete.

Please wait patiently and do not press the **Back Button** during this time. Interrupting the process may prevent the camera from connecting to your **Wi-Fi** or network properly

Name Your Device

Set a custom name for your device (e.g., “Front Door Camera” or “Garage Cam”) to help you identify it easily.

After entering the name, click **“Complete”** to successfully add the device.



5) If the QR Code Is Missing or Not Working

If the QR code on the device is unavailable or cannot be scanned, please follow the instructions below to add your device manually.



• Device Power-On Confirmation

On the Add Device screen, follow the on-screen instructions. If you need an alternative way to add your device, click the **More Method** option located in the upper-right corner of the screen.



5.1) Adding Camera via LAN


- If your camera is connected to the router via **LAN** and your mobile device is on the **same network**, select the **LAN Scan** option to automatically detect and add the camera.



6) Preview Interface

To access the live view:

- Click the **Device Thumbnail** in the list to enter the **Preview Interface**.




7) SD Card Recording Playback and Video Download SD Card Playback:

1. SD Card Playback

- Tap **“SD Card Recording”** on the playback screen to view recorded videos stored on the SD card.

2. Video Download


- Tap the **“Download”** icon on the playback screen to save the selected video.
- During the download, tap the progress bar to check the current download status.



8) Installation and Placement


8.1 3MP Wi-Fi Bullet Camera

1. Select a suitable wall bracket and install the bracket to the wall, using the fixtures & screws. Mount the camera to the bracket.
2. Tighten the vertical and horizontal adjustment screws to adjust the camera to the desired monitoring scene, and then tighten the adjustment screws to complete the installation.



Wall Installation

8.2 3MP Wi-Fi Dome Camera



Ceiling Installation



Ceiling Installation

Warning



In case of fire or lightning, pls don't put product in damp and raining place. Operate or maintain only according to the user manual.



Be careful when you see an attachment with the Dangerous Voltage Sign which might cause serious electric accident.

	Warning CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN	
Warning	To reduce electric shock, unprofessional people please don't open product front panel or rear panel	

Warning In case of electric shock and fire, pls don't use power supply beyond power list in user manual

Notice:

- Ensure your equity, please read the user manual carefully before you use the product
- Please contact professional people if you need install and maintain the product
- Working Environment : temperature of -20°C~+60°C, relative humidity under 85%
- Please do not exceed the standard range of temperature, humidity and voltage as suggested in the user manual.