

artifax

RECHARGEABLE DOUBLE

MIST FAN

ART-BM-2



Contact Information



+91-8459059329



care@artifax.in



www.artifax.in

Product Overview

The Double-Ended Spray Fan is a versatile, portable fan designed to provide cool airflow with the added benefit of a refreshing mist. Ideal for staying cool in hot weather, it features a dual fan system, a 280ml water tank, and a 90-degree rotatable head for customizable airflow direction.

Features

- **Dual Fans:** Dual-ended fans for optimal airflow.
- **Spray Function:** Built-in mist spray for added cooling comfort.
- **Brushless Motor:** Efficient, durable motor for quiet operation.
- **3 Adjustable Speeds:** Choose from three gears for different wind levels.
- **90-Degree Rotation:** Adjustable fan head for customizable airflow direction.
- **Removable Front Cover:** Easy to clean and maintain.
- **Long Endurance:** Designed for extended use with a large water tank (280ml).
- **Compact Size:** 373mm x 160mm x 89mm, portable and easy to handle.

Technical Parameters

Input: 5V-2.0A

Power: 10W

Motor Type: Brushless Motor

Tank Capacity: 280ml

Size: 373mm x 160mm x 89mm

Rotation: 90-degree adjustable

Gears: 3 speed settings

Cooling Mist: Yes (Spray function)

Troubleshooting

- **Fan does not turn on:** Ensure the fan is fully charged and the power button is working.
- **Weak airflow:** Clean the fan blades and ensure the mist function is not blocked.
- **Mist not spraying:** Check the water tank for sufficient water. Refill if necessary.
- **Not charging:** Try using a different charging cable or power source.
- **Fan not rotating:** Check if the fan head is obstructed. Ensure the fan is securely assembled and that there are no blockages preventing movement.
- **Fan makes noise:** Check if the fan blades are clean and free of debris. Make sure the fan is assembled correctly and securely.

How to Use

- **Filling the Water Tank:** Remove the front cover, fill the 280ml tank with clean water, and secure the cover.
- **Charging the Fan:** Connect to a 5V-2.0A power source via the USB cable. Charge for 4-5 hours.
- **Turning the Fan On:** Press the power button to turn the fan on.
- **Adjusting Speed:** Press the speed button to select from 3 settings: Low, Medium, High.
- **Activating the Mist:** Press the mist button to release a cooling spray.
- **Adjusting Fan Direction:** Tilt the fan head up to 90 degrees to change airflow direction.
- **Cleaning:** Turn off the fan and unplug before cleaning the fan and water tank.

Using Mist: Use only RO water to avoid clogging. Turn on/off the mist spray as needed.

Caution and Safety Guidelines

- **Charging:** Use the provided USB cable and 5V-2.0A power source; avoid overcharging.
- **Battery Care:** Avoid extreme temperatures and disassembly.
- **General Use:** Keep away from moisture and ensure stability.
- **Cleaning:** Turn off the fan and wipe with a dry cloth; don't immerse in water.